## **Dam Safety - Jurisdictional Dam Data Dictionary**

This document describes the Dam Safety - Jurisdictional Dam dataset in the Colorado Information Marketplace.

A Jurisdictional Dam is a dam creating a reservoir with a capacity of more than 100 acre-feet, or creates a reservoir with a surface area in excess of 20 acres at the high-water line, or exceeds 10 feet in height measured vertically from the elevation of the lowest point of the natural surface of the ground where that point occurs along the longitudinal centerline of the dam up to the crest of the emergency spillway of the dam. For reservoirs created by excavation, or where the invert of the outlet conduit is placed below the surface of the natural ground at its lowest point beneath the dam, the jurisdictional height shall be measured from the invert of the outlet at the longitudinal centerline of the embankment or from the bottom of the excavation at the longitudinal centerline of the dam, whichever is greatest. Jurisdictional height is defined in Rule 4.2.19. The State Engineer shall have final authority over determination of the jurisdictional height of the dam.

## **Data Dictionary**

| Field Name      | Description   | Data Type |
|-----------------|---|-----------|
| DAMID           | Unique SEO Dam ID   | Text      |
| Dam Name        | Official name of the Dam  | Text      |
| Other Dam Names | Names other than the official name (i.e., reservoir name) of the dam in common use. | Text      |
| NID ID          | National Inventory of Dams ID (USACE)   | Text      |
| WDID            | SEO Administrative Structure WDID for the reservoir.                                | Text      |
| Physical Status | Indicates physical status of dam  | Text      |
| DIV             | Division where the Dam is located.  | Number    |
| WD              | Water District where the Dam is located.  | Number    |
| County          | County where the Dam is located.  | Text      |
| PM              | Principle Meridian.   | Text      |
| Township        | Township  | Text      |
| Range           | Range   | Text      |
| Section         | Section   | Number    |

| Q160              | 160 acre quarter section indicator.   | Text   |
|-------------------|---|--------|
| Q40               | 40 acre quarter section indicator.  | Text   |
| UTM x             | The x (Easting) component of the Universal Transverse Mercator system. (NAD83 datum)  | Number |
| UTM y             | The y (Northing) component of the Universal Transverse Mercator system. (NAD83 datum)   | Number |
| Location Accuracy | Accuracy of UTM coordinates.  | Text   |
| Latdecdeg         | Latitude (decimal degrees)  | Number |
| Longdecdeg        | Longitude (decimal degrees)   | Number |
| Stream            | Official name of the river or stream on which the dam is built. If the stream is unnamed, identify it as a tributary to a named river, e.g., Snake-TR. If the dam is located offstream, enter the name of the river or stream plus "-OS", e.g., Snake-OS.   | Text   |
| Downstream Town   | Name of the nearest city, town, or village that is most likely to be affected by floods resulting from the failure of the dam.  | Text   |
| Town Distance     | Distance from the dam to the nearest affected City/Town/Village, to the nearest mile (and tenth if appropriate).  | Number |
| Year Completed    | Year when the original main dam structure was completed.  | Number |
| Purposes          | The purposes for which the reservoir is used:     I for Irrigation;     H for Hydroelectric;     C for Flood Control and Storm Water Management;     N for Navigation;     S for Water Supply;     R for Recreation;     P for Fire Protection, Stock, Or Small Farm Pond;     F for Fish and Wildlife Pond;     D for Debris Control;     T for Tailings;     O for Other. | Text   |

|                     | The order should indicate the relative decreasing importance of the purpose. Codes are concatenated if the dam has multiple purposes.  |        |
|---------------------|--|--------|
| Federal Land        | Indicates whether dam is a non-federal dam located on federal property.  | Text   |
| Federal Regulations | Federally Owned Dam or private dam subject to federal regulations (i.e. FERC)  | Text   |
| Dam Type            | Indicates the type of dam:  RE for Earth; ER for Rockfill; PG for Gravity; CB for Buttress; VA for Arch; MV for Multi-Arch; CN for Concrete; MS for Masonry; ST for Stone; TC for Timber Crib; OT for Other. Codes are concatenated if the dam is a combination of several types. For example, the entry CNCB would indicate a concrete buttress dam type. | Text   |
| Dam Length          | The length, in feet, of the dam which is defined as the length along the top of the dam. This also includes the spillway, power plant, navigation lock, fish pass, etc., where these form part of the length of the dam.   | Number |
| Dam Height          | The height of the dam, in feet to the nearest foot, which is defined as the vertical distance between the lowest point on the crest of the dam and the lowest point in the original streambed.   | Number |
| Crest Elevation     | The elevation above mean sea-level of the nearest foot of the crest of the dam.  | Number |
| Normal Storage      | The normal storage, in acre-feet, which is defined as the total storage space in a reservoir below the normal retention level, including dead and inactive storage and excluding any flood control or surcharge storage.   | Number |

| Surface Area         | The surface area, in acres, of the impoundment at its normal retention level.  | Number |
|----------------------|--|--------|
| Drainage Area        | The drainage area of the dam, in square miles, which is defined as the area that drains to a particular point (in this case, the dam) on a river or stream.  | Number |
| Spillway Capacity    | Combined capacity of all spillways on a dam in cubic-feet per second.  | Number |
| Outlet Description   | Type of outlet on a dam (i.e Steel pipe, Concrete pipe, Tunnel, etc.)  | Text   |
| Outlet Capacity      | Capacity of the outlet in cubic-feet per second.   | Number |
| Outlet Inspection    | Date of the outlet inspection.   | Date   |
| Hazard Class         | Hazard classification of the dam.  | Text   |
| EAP                  | Indicates whether this dam has an Emergency Action Plan (EAP) developed by the dam owner. An EAP is defined as a plan of action to be taken to reduce the potential for property damage and loss of life in an area affected by a dam failure or large flood. Y for Yes; N for No; NR for Not Required by submitting agency. | Text   |
| EAP Date             | Date Emergency Action Plan was submitted.  | Date   |
| EAP Inundation Map   | Emergency Action Plan included an inundation map.  | Text   |
| Inundation Map Date  | Date inundation map was created.   | Date   |
| Last Inspection Date | Date of the most recent inspection of the dam  | Date   |
| Overall Condition    | Overall conditions on the dam as determined during the last inspection.  | Text   |
| Safe Storage         | Recommended safe storage levels as determined during the last inspection.  | Text   |
| Inspector            | Person or agency who performed the last inspection.  | Text   |

| Current Restriction | Flag indicating if Dam is currently under restriction.  Contact the Division office for additional details. | Text     |
|---------------------|---|----------|
| Primary Name        | Person/Agency who owns the dam  | Text     |
| Primary Contact     | Person representing the owner.  | Text     |
| Assigned To         | The Dam Safety engineer assigned to the dam   | Text     |
| More Information    | Link to Dam Safety web page.  | URL      |
| Location            | Latitude/Longitude where the Dam is located. Used in Marketplace for mapping.                               | Location |